



**Turn light guards Kit
Discovery L319 / RRSport L320
Installation guide**

Cod. LRP007013

Congratulations on your purchase!

With this kit you can easily install our Turn Light guards on your Discovery 3, Discovery 4 or Range Rover Sport L320.

The installation is simple and reading this guide it can be done by everyone, without special competence or specific equipment, just a few patience!



PLEASE READ THESE INSTRUCTIONS COMPLETELY BEFORE PROCEEDING WITH INSTALLATION

Please take the time to read and understand this manual so that you can correctly install the purchased product.

These symbols you will find into the instruction's manual have the following meaning:



SUGGESTION: Indicates important information for the correct installation of the product




ATTENTION: it indicates an important warning and failing to respect the indications supplied can cause damage to the vehicle



Turn light guards Kit Discovery L319 / RRSport L320 Installation guide

Cod. LRP007013

1. Kit part list

Cod	Description	image
A	Turn lighth guard (x2)	
B	M4 rivnuts (x8)	
C	M4 bolts (x8)	

2. Compatibility:

- Land Rover Discovery 3/LR3 – L319
- Land Rover Discovery 4/LR4 – L319
- Range Rover Sport MKI – L320

3. Tools needed:

- Paper tape
- Pencil/Marker
- Punch drill
- Drill
 - 3mm bit
 - 6mm bit
- Rivnut tool
- Allen key #2.5

4. Installation:

4.1. How to mark hole points



Due car door shape, on Discovery L319 the light guard must always be placed with LRP logo on the right of the turn light as shown in the following pictures. On Range Rover Sport L320, it can be placed either on the right or left side.

Attach one piece of paper tape above and one below to the turn light:



place the light guard in the center and with a pencil mark the 4 points where to make the holes:



Using the drill punch, mark again the drill points. Pushing the turn light to the right and pulling it toward you, remove it from the door:



4.2. It's time to drill

Using the 3mm bit first and then the 6mm bit, drill all marked points:



Be carefull to not drill the turn light wires. Take your time to check where wires runs inside the door!



Use the rivnut tool to install provided M4 rivenuts:



Insert in place the turn light and the 2.5 Allen key install the light guard:





**Turn light guards Kit
Discovery L319 / RRSport L320
Installation guide**

Cod. LRP007013

Check your turn light and.... well done! Installation completed!

