



**Discovery 4/LR4 Facelift
Fog Light guards kit
Installation guide**

Cod. LRP007015

Congratulations on your purchase!

With this kit you can easily install our Fog Light guards on your “facelift” Discovery 4/LR4.

The installation is simple and reading this guide it can be done by everyone, without special competence or specific equipment, just a few patience!



PLEASE READ THESE INSTRUCTIONS COMPLETELY BEFORE PROCEEDING WITH INSTALLATION

Please take the time to read and understand this manual so that you can correctly install the purchased product.

These symbols you will find into the instruction’s manual have the following meaning:




SUGGESTION: Indicates important information for the correct installation of the product



Discovery 4/LR4 Facelift Fog Light guards kit Installation guide

Cod. LRP007015

1. Kit part list

Cod	Description	image
A	Fog light guard kit (x2)	
B	Snap Rivets (x8)	
C	M4 bolts (x8)	

2. Compatibility:

- Land Rover Discovery 4/LR4 – L319 “FACELIFT front bumper”

3. Tools needed:

- Drill
 - 4mm bit
- Allen key #2.5

4. Installation:



Following picture refer to right side. Letters in red circles should always be positioned at the bottom and indicate the position relative to the fog light ring. "I = Inner; O = Outer"



Take the bracket I and put it in place. The rounded part should be in contact with the fog lamp ring. Using 4mm bit, drill a little bit the fog light bezel to mark where to drill the holes:



Remove the bracket and drill 2 holes where marked:



Put the bracket on place again an insert the snap rivets provided:



Repeat the procedure with the "Outer" bracket:



Using 2.5 Allen key install the light guard:



Repeat the entire procedure for the opposite side and.... well done! Installation completed!

